

3360

High Back French Counterstool

Chairs, Sofas & Barstools



(Barstool is 6859)

W20 3/4 x D21 1/4 x H44 1/2

Seat height: 26

Standard with double welt when using fabric and with antique brass nailhead trim when using leather

A1) Rush seat

B1) Upholstered seat

COM required: 1 yard plain

C1) Upholstered seat and back

COM required: 2 yards plain



Bausman & Company

1425 South Campus Avenue, Ontario CA 91761 . 909.947.0139 . Fax 909.947.4508 . bausman.net