

W93 1/4 x D24 x H86

(Overall width at crown: 98")

A1)

Upper: W90 3/4 x D14 3/4 x H56 Open with false back for TV and seven adjustable wood shelves

Lower: W23 3/4 x D24 x H30 With three drawers and four doors. Each door with two adjustable wood shelves behind

Space available for TV:
W45 1/4 x D6 x H29
Space available behind side doors:
W17 3/8 x D17 x H16 5/8
Space available behind each center door:
W20 5/8 x D21 x H16 6/8

